



Streamtek Corp. brings you solutions for a new economy.

Ionizing Bar

Installation & Maintenance Guide

Ionizing Bar is a shock-less superior performing ionization static elimination bar which is both rugged & compact in design. It delivers highly positive (+) and negative (-) ion output in cramped quarters.



Version 1.0



CONTACT

ADDRESS

Streamtek Corp. – Canada,
6-295 Queen Street
East Suite 384
Brampton ON.,
L6W 4S6

PHONE & FAX

US & Canada phone : 1-888-218-6548
Worldwide phone: 1-705-770-4455

US & Canada phone : 1-888-218-6548
Worldwide phone: 1-705-770-4455

ONLINE

Sales Email: sales@stream-tek.com
Tech Help Email: support@stream-tek.com

Website: www.stream-tek.com

01 Electrical Requirements

02 Mounting the power supply

03 Installation

01 Electrical Requirements

A 6-1/2 foot grounded power cord is supplied with the power supply. The unit must be plugged into a grounded outlet or wired to a grounded control box.

Ratings

Input Volts: 115VAC Standard (220VAC Optional)

Output Volts: 6,000VAC

Cycles: 50/60

Starting Load: <0.5 amps

Running Load: <0.5 amps

02 Mounting the power supply

The Power Supply can be mounted to any solid surface via the mounting tabs extending out from the bottom side of the unit or placing the unit in an enclosure. Keep in mind the positioning of the Ionizing Bar when locating the Power Supply. A standard 6-1/2 foot power cable is supplied with the bar.

Once the unit has been mounted, switch the unit to the OFF position (the lighted rocker switch is located on the side of the unit near the cord end—rock the switch downward) and then route the power cord to the designated outlet. (The Power Supply can be wired directly to a machine switch so the unit is only running when the machine is running and off when it is not.) The Power Supply is now ready to receive the Ionizing Bar.

Note: Always keep the Power Supply powered OFF when the system is not in use. Unplug or disconnect the power to the controller when the system is being serviced.

03 The Ionizing Bar Installation

The STREAMTEK Ionizing Bar is a one piece, lightweight unit. The in-line high voltage cable has a screw-in type connector enabling quick and easy hook-up to the power supply.

At each end of the bar are positioned an 8/32 stud and nuts that can be fastened to a mounting bracket or chain, not supplied. Longer bars will have mount student and nuts positioned symmetrically in the middle of the bar.

Positioning the Bar

The tip of the emitters should be directed straight at the static laden surface. The bar should be positioned so that it spans the full width of the area or substrate that is to be neutralized. This will ensure maximum ionization coverage and static neutralization.

For best performance, it is important that there are non-targeted electrically conductive surfaces in close proximity of the tips of the emitters. It is best if a minimal free air space of 6" (inch) is maintained in front of and alongside the emitters and the surface that is to be neutralized. Please note that this is for **best** performance. The unit will perform and no harm will occur to the system if the 6" buffer cannot be maintained due to tight space limitations.

03 Installation

04 Maintenance

Once the best location for the bar has been determined and all the proper mounting hardware has been installed, the bar is ready for installation. Make sure the bar is mounted securely via the studs.

Power Cable Connection

Before connecting the bar to the Power Supply, be certain that the rocker switch is set to the OFF position or disconnected from electrical power. Screw the high voltage connector into either jack of the Power Supply. Each jack has the same output voltage. Where multiple bars are installed, two bars can be plugged directly into the Power Supply.

NOTE: If any excess cable has to be coiled, do not coil any tighter than a 6" (inch) diameter coil. Doing so may cause internal damage to the cable and cable failure. Connect the ground wire to the ground stud located on the power supply.

CAUTION: If the cable is connected or disconnected to the Power Supply when the power is ON there is the risk of personal shock and/or damage to the Power Supply.

Power-Up

Once call connected and final installations have been made, the system is ready for use. Turn the switch ON (rock upward toward the enclosure lid). In the ON position the switch will glow red.

04 Maintenance

With some simple preventive maintenance procedures the Streamtek Ionization System will give years of service. Special care should be taken with the Power Supply and bar as with any sensitive electronic device. Do not drop or shake the Power Supply or Bar. Avoid mounting the Power Supply or Bar to surfaces that would have excessive vibration or rapid motion. Always handle the Bar by the body of the Bar and do not tug or jerk on the power cable.

Keep the Power Supply and Bar dry and clean. Each power supply is supplied with two jack covers and these should remain in place when the jack is not being used. Avoid exposing the system to moisture or solvents of any kind. Dust and other contaminants can be removed by using a soft cloth by itself or along with a gentle, general purpose cleaner.

Remove dust and other contaminants from the Bar taking special care around the emitter points. If need to be, a cleaner for use with ABD/PVC and aluminum can be used sparingly. If cleaners are used make sure the Power Supply and Ionizing Bar are dry before operating them.

Service

In the event of equipment damage or failure, call the factory for service or repair, 705-770-4455 or Toll Free 888-218- 6548. There are no field serviceable parts on the system. Outside of cleaning, do not attempt to service or repair the system. Personal shock and/or damage to the system could occur. Any attempted field service or repair will void the Warranty.

05 Warranty

All Streamtek Static Elimination products are engineered and designed with optimum serviceability in mind. Quality of materials and labor are foremost in the manufacture of our products. In the event that there is any premature failure of our system, the Ionizing Bar is guaranteed against any factory defects in materials and/or workmanship for a full **12 months** from the date of purchase.

Any static elimination equipment found to be defective by a qualified Streamtek service technician will be repaired or replaced at Streamtek's cost. Any special handling or shipping the customer may request is not covered under this warranty. All Warranties are void if the equipment has been damaged due to negligence, misuse, or any other even outside of the control of the manufacturer.

Call the factory before returning any equipment under Warranty, 705-770-4455 or 888-218-6548.

04 Health and Safety

The Streamtek Ionizing Bar has been engineered for safe and user friendly operation. Please operate this system safely by observing the following:

- The Power Supply is a High Voltage source. **Do Not** attempt to dismantle or tamper with the unit. Personal electrical shock and/or damage to the unit may occur.
- The Power Supply **must not** be operated under any circumstance with the housing lid removed or when the housing is damaged in anyway.
- **DO NOT** operate the Power Supply without the unit being electrically grounded. A grounded power cord has been provided with the unit and should be used at all times with a grounded outlet or control box.
- **ALWAYS** turn the Power Supply **OFF** or disconnect power to the unit before unplugging the Bar or cleaning the system. Not doing so could result in personal electrical shock and/or damage to the unit.
- The emitters on the Ionizing Bar are resistively coupled with 100Mohm resistance in series with the high voltage source that makes the emitters shock less when touched individually. **DO NOT** allow personal contact with more than one point at a time. In general, contact with emitters should be avoided.
- By design, the Streamtek Ionizing Bar emitters are very sharp. Take care when handling the bar.
- It is recommended that all electrically conductive surfaces in the Ionizing Bar field be earth grounded to prevent those surface from becoming electrically charged by the AC source.
- A byproduct of the Streamtek Ionizing Bar is ozone. The ozone emission from the Bar is less than 0.1ppm and well below OSHA standard providing safe working conditions around the system.